


### Nomenclature

- = Control ON / OFF
- = AM / PM
- = Program
- = Temperature
- = Time
- = Enter


### Creating a 10:1 Menu Item

**Note:** You must get from step 1 thru step 3 within the 10 sec. time frame or you will have to re-enter the passcode.

1. Press the “PROGRAM” key. The LED display will read “ENTER PASSCODE”.



2. Enter the manager’s passcode by pressing the following keys in the order shown:



Press the “ENTER” or “OK” key.


3. Using the “UP” key, select the desired AM/PM option and press the “ENTER” or “OK” key to accept.




4. For the “REMOVE IN” option use the “ON/OFF” key to scroll left or right and the “UP ARROW” to change the number. Press the “ENTER” or “OK” key to accept.




5. Using the “UP ARROW” key, select the “MANUAL” or “AUTO” options and press the “ENTER” or “OK” key to accept.




6. Using the same keys in Step 4, enter in your “REMOVE GAP” numbers. Press the “ENTER” or “OK” key to accept.



7. Enter in your “STAGE 1 TIME” numbers. Press the “ENTER” or “OK” key to accept.



8. Enter in your “**STAGE 1 GAP**” numbers.  
Press the “**ENTER**” or “**OK**” key to accept.




9. Enter in your “**MUST REMOVE IN**” numbers.  
Press the “**ENTER**” or “**OK**” key to accept.




10. Enter in your “**PREP BREAD IN**” numbers.  
Press the “**ENTER**” or “**OK**” key to accept.




11. Enter in your “**PREP ALARM IN**” option.  
Press the “**ENTER**” or “**OK**” key to accept.




12. Enter in your “**TOP TEMP**” numbers.  
Press the “**ENTER**” or “**OK**” key to accept.




13. Enter in your “**BOTTOM TEMP**” numbers.  
Press the “**ENTER**” or “**OK**” key to accept.



14. Enter in your “**AUTO SELECTION**” option.  
Press the “**ENTER**” or “**OK**” key to accept.



15. Enter in your “**AUTO GAP**” options.  
Set in the first group of numbers (ex:230),  
Press the “**ENTER**” or “**OK**” key to accept.  
Set in the second group of numbers (ex:330),  
Press the “**ENTER**” or “**OK**” key to accept.



**Return to the Main Menu**

1. Press the “**PROGRAM**” key twice.
2. Press the “**RIGHT ARROW**” key once.